

An interactive game with children using QTrobot

GAO Chongkai






Background: The Experiment



Children with DYSTONIA:

a movement disorder in which your muscles contract involuntarily, causing repetitive or twisting movements.

Orthoses Experiment



QTrobot Experiment

Playing with a screen Playing with QTrobot
The number of times
they want to play

day1	day2
Orthoses Power Off & Playing with a screen	Orthoses Power Off & Playing with QTrobot
Orthoses Power On & Playing with a screen	Orthoses Power On & Playing with QTrobot





Thumb Angle Detection




Tools: OpenCV, Astra pro camera, ROS CV_bridge Steps:

- 1. use ROS subscriber to get camera images from ROS topic
- 2. use Gaussian Mixture-based Background/Foreground Segmentation Algorithm to get the mask and then get the foreground image(hand)
 - 3.use image erode algorithm and Gaussian filter to remove noise
 - 4.find the center of hand
- 5.find the contour of hand and get the point furthest away from the center, and then calculate the angle by connecting the two points
 - 6. use the result to define thumb up/down



Thumb Angle Detection -- Video Demo









QTrobot -- NumberGame



Play NumberGame:

Ask questions -> Thumb up/down -> Detect the angle -> Give encouragement or reward



QTrobot -- Behaviors and Functions



Gesture: 18 different gestures for 6 different categories Emotion: 10 different emotions for 6 different categories

Talking: 4 or 5 sentences for every step

Encouragement: for not doing well

Reward: for doing well

Methods:

use camera result, fatigue level, past responses and past encouragement/reward to decide the probability of encouragement/reward of this step

MDP?



QTrobot -- Video Demo







Later Works



- 1.Combine all parts
- 2. Find a proper way to record different kinds of data
- 3.Do the experiment







Thanks for listening

GAO Chongkai



